


Remote Controller Manual



MODEL

NR-21DU

Keep this manual near this remote controller for future reference whenever maintenance or service is required.

NAVIEN User Manual

Contents

Safety Instructions	3
Included Items	4
Connecting the Extension Cable	5
Attaching the Wall Mounting Bracket	6
Remote Controller	7
LCD Display Icons	8
Multi Remote Controller System	9
Turning the Controller On or Off	14
Setting the water temperature	15
Entering High Temperature Mode (Commercial Mode)	16
Entering Lock Mode	17
Starting Recirculation	18
Setting the clock	19
Setting the Recirculation timer	21
Canceling all timer settings	24
Additional features for Cascade systems	25
About errors and icons	26
About scale warning	27
Basic Troubleshooting and Frequently Asked Questions	28
Error Code Guide	30

Safety Instructions

The following safety symbols are used in this manual. Read and follow all safety instructions in this manual precisely to avoid unsafe operating conditions, fire, explosion, property damage, personal injury, or death. Keep this manual for future reference.



WARNING

If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life.



DANGER

Indicates an imminently hazardous situation which, if not avoided, could result in severe injury or death.



WARNING

Indicates a potential hazardous situation which, if not avoided, may result in injury or death.








CAUTION

Indicates a potentially hazardous situation that, if not avoided, could result in property damage.

Included Items


When you open the box, you will find the following items with the remote controller. Check the box for each of the following items before installing the remote controller.

		
User Manual	Extension Cable	2 Tapping Screws


	
Wall Mounting Bracket	Multi Remote Controller Cable (optional)

Connecting the Extension Cable


1. Connect one end of the extension cable to the port on the front panel of the water heater.
2. Pass the other end of the extension cable through the hole in the bracket.



3. Connect the end of the extension cable to the cable connected to the remote controller.




Note You can connect up to 2 remote controllers if necessary.(Optional)




Attaching the Wall Mounting Bracket

1. Affix the bracket securely to the wall by fastening 2 screws to the wall or to the 2 holes in the wall receptacle.




On the wall



In the wall receptacle

2. Hang the remote controller on the bracket by aligning the hooks.

Remote Controller



LCD Display Icons



Timer is set.



Recirculation Mode.



Displays the current time.



Hot water is in use.



Displays the current set temperature.



Water heater operation is in progress.



Operations are locked.



An error code will appear on the display.

Multi Remote Controller System

The multi remote controller system consists of one main remote controller and one sub remote controller. The system must have only one main remote controller.

Initially Setting the Multi Remote Controller System

If you turn on the water heater with the front panel connected to two remote controllers, one of the controllers is set to the main controller randomly. The other controller will display "MAIN" on its LCD display and you have to set its operation mode to Sub.



The remote controller that does not display "MAIN" is already operating as the main controller, you don't have to set its operation mode.

You can set the operation mode of the remote controller that displays "MAIN." When you set the controller as a sub, the multi remote controller system configuration completes.

Note

If you press the OK button on the controller displaying "MAIN" and set its operation mode to Main while the main controller has already been determined, the other controller will display "MAIN" to indicate that you must set the main and sub operation modes properly.

Multi Remote Controller System

1. Press the Down button on the remote controller displaying "MAIN" to set its operation mode to "SUB."



Then, press the OK button to set the operation mode to Sub.

2. "SL.xx" appears on the display.
It represents the standby status to receive the sub remote controller ID from the main remote controller synced to the front panel of the water heater.



Multi Remote Controller System

- When the ID is assigned, the ID appears and flashes on the LCD display for 2 seconds.




- "SYNC" appears on the LCD display for 5-10 seconds until it syncs with the connected panel and the main remote controller after the ID is assigned.



Multi Remote Controller System


- When the synchronization completes, identical information will appear on the displays of the main and sub controllers. The two controllers and front panel will be controlled simultaneously by controlling only one controller.



Checking the Multi Remote Controller System Setting

After completing the multi remote controller setting, you can check the setting by pressing the OK button and Lock button simultaneously for 2 seconds.

Verify that the setting is successful by confirming that one controller displays "MAIN" and the other one displays "SUB."




Multi Remote Controller System

Initializing the Multi Remote Controller System Setting

You can initialize the multi remote controller system when you have to reset or replace the multi remote controllers. Press the Preheat & Timer button and Lock button simultaneously for 2 seconds on any of the controllers.


After initializing the setting, repeat the instructions from the “Initially Setting the Multi Remote Controller System” on page 9.



Note

If you initialize only one of the controllers, the other one is initialized automatically.

Turning the Controller On or Off




To turn the controller on or off, press the Power button.

When the power is on,

- The LCD display turns on.
- The LED indicator turns green.
- Hot water temperature is displayed.

- Note**
- When an error occurs, the LED indicator turns RED and blinks (except for Cascade mode).
 - The backlight stays on for 8 seconds when a button is pressed.

Setting the water temperature



WARNING Setting the water temperature above 125°F (52°C) can cause instant scalding or severe burns.

The Range of temperature settings is different depending on the Water Heaters.

Range : 98 ~ 140°F (36~60°C)

- NPN Non-Condensing Water Heaters
Range : 98 ~ 140°F (36 ~ 60°C)
- NPE-A2/S2 Condensing Water Heaters
Range : 97 ~ 140°F (36 ~ 60°C)
- Press the Up or Down button to adjust the temperature. The temperature changes by 1°F (0.5°C)

Note

- The settings are automatically saved when you do not press any buttons for 5 seconds.
- For temperature higher than 140°F(60°C), Check the High Temperature mode in the next section.

Entering High Temperature Mode (Commercial Mode)

1



Press and hold the Up and Down button simultaneously for 10 seconds.

- When this mode is available, "HIGH" appears for 3 seconds.
- When this mode is unavailable, "LoW" appears for 3 seconds.



To prevent instant scalding or severe burns, check the set temperature before using hot water.

2




Press the Up button to increase the temperature by 1°F(0.5°C), and press the Down button to decrease the temperature by 1°F(0.5°C)

Note

- Commercial Warranty applies when this mode is used. Refer to the Warranty in the Operation manual for more details.
- Commercial mode is only available for select models. Refer to the Operation Manual supplied with the water heater.

Entering Lock Mode



To prevent accidental pressing of the buttons and to prevent children from adjusting the controller, you can activate the Temperature Lock Mode.

To activate or deactivate Lock Mode, press the Lock button for 2 seconds.

When Lock Mode is activated,

- The Lock icon appears on the display.
- All buttons except for Lock button are locked.

Note

- Resetting errors or alarms is still available with Lock Mode activated.
- You can change the settings from the front panel with Lock Mode activated.

Starting Recirculation

Press the Preheat & Timer button to start recirculation immediately, regardless of the reservation schedule. "HEAT" appears for 4 seconds on the display and then recirculation runs once.



During the recirculation, when NPN Non-condensing water heaters are connected, The preheating icon flashes continuously.

when NPE-A2/S2 condensing water heaters are connected, The preheating icon keeps turning on.

Note

- This feature is available only when external circulating pumps are connected and ON.
- This feature runs during the recirculation time set on the front panel which the remote controller is connected to.

Setting the clock

1




Press the Timer button for 2 Seconds.

Note

Setting the clock is available only when NPN Non-condensing water heaters are connected.


2



Adjust the minutes by pressing the Up or Down Button.

Press the OK button to set the minutes.

3




Once the minutes are set, adjust the hour by pressing the Up or Down button.

4



Press the OK button to finish and save the updated time.


Setting the Recirculation timer



Press the Timer button twice to set the Recirculation timer.

Reservation Schedule #1 is ready to be set.

Note Setting the Recirculation Timer is available only when NPN Non-condensing water heaters are connected.




Set the recirculation activation time by pressing the Up or Down button.

Press the OK button to set the deactivation time.

Note The recirculation timer settings are divided in 30 minute increments.

3




Set the deactivation time by pressing the Up or Down button.

4




Press the OK button to save the timer setting.
Repeat these procedures for Reservation Schedule Settings #2 and #3.

5



During the reservation schedule, the preheating icon turns on and the Reservation area starts flashing.

Canceling all timer settings



Press and hold the Timer and OK button simultaneously for 2 seconds.

"CLR" appears for 3 seconds and all timer settings are canceled.

Note Canceling all timer settings is available only when NPN Non-condensing water heaters are connected.

Additional features for Cascade systems

Standby feature before On/Off

This feature allows the system to stand by until the Power is switched to On or Off.

"WAIT" is displayed while the entire Cascade water heater is powered ON or OFF.



Note

This is applied to models with Cascade systems only.

System info on the Slave panel

When the remote controller is connected to the wrong panel, its ID is displayed on the LCD display as an error. In this case, you cannot control or change the settings.

Connect the remote controller to the Master panel correctly.



About errors and icons

Depending on the severity of the issue that is causing the error, the water heater will either stop its operation or will only be able to perform basic operations. A flashing red LED and error icon can be seen on the remote controller along with the associated error code.

The error code is displayed in 3 digits. (see below).



Reset errors

After the problems that are causing the errors are resolved, press the OK button once and "RST" will be displayed on the LCD display.



For Cascade systems

Regardless of error levels, the following is displayed in turn: Current status, error code, and Cascade ID.

You can reset errors manually in order to allow the water heater to continue operation.

About scale warning

Scale warning

When the water heater needs to be cleaned, the scale alarm is activated.

Current status and scale alarm code is displayed.

You can change the scale warning intervals if desired.



Deactivating the scale alarm

Press and hold the OK button for 2 seconds.

"RST" is displayed for 3 seconds.



For Cascade systems

The following is displayed in turn:

Current status, alarm code, and Cascade ID.

You can change the settings and control them.

Note For details, see the Operation manual.

Basic Troubleshooting and Frequently Asked Questions

- If you experience a problem with the water heater, refer to the following chart for possible remedies. Error codes that appear on the front panel display are explained in the following section.
- For minor problems, resetting the water heater may resolve the issue. To reset the water heater, press the Reset button on the front panel.
- If resetting the water heater and attempting the remedies suggested in the following do not resolve the problem, contact an authorized technician, a licensed professional, or Navien Technical Support at 1-800-519-8794 for service instructions.

Problem	Possible Cause(s)	What to do
No water comes out when the hot water tap is opened.	<ul style="list-style-type: none">• Is the cold water inlet filter clean?• Is an error code displayed on the front panel?• Is the water heater frozen?	<ul style="list-style-type: none">• Ensure that the shut-off valves on the hot and cold pipes are open.• If an error code is displayed, refer to the Error Code Guide.
It takes too long for hot water to reach the fixtures.	Are you using the external recirculation mode?	Have a contractor install a recirculation return line from the furthest faucet back to the water heater.

Problem	Possible Cause(s)	What to do
The water from the hot water faucet is cold or turns cold and stays cold.	<ul style="list-style-type: none"> • Is the cold water inlet filter clean? • Is the hot water faucet open wide enough draw at least 2 liters of water per minute (LPM) through the water heater? • Is an error code displayed on the front panel? • If there is an external recirculation system installed, is there a check valve on the recirculation return line? 	<ul style="list-style-type: none"> • Clean the cold water inlet filter. See "4.4 Cleaning the Inlet Water Filter and Recirculation Inlet Filter" in the Operation manual. • Open the hot water faucet completely. • If an error code is displayed, refer to the Error Code Guide.
The water is not hot enough.	Is the set temperature too low?	<ul style="list-style-type: none"> • Check the water heater's temperature setting. Refer to "3.2 Adjusting the Water Temperature" in the User's information Manual. • Check for cross plumbing between the cold and hot water lines.
The water is too hot.	Is the set temperature set too high?	<ul style="list-style-type: none"> • Check the water heater's temperature setting. See "3.2 Adjusting the Water Temperature" in the User's information Manual.

Error Code Guide

Error Code	Reason	Self-diagnostic / Action
E003	Ignition failure	Ensure that the main gas supply valve is open.
E004	False flame detection	Ensure that the electrical cord is properly grounded.
E012	Flame loss	<ul style="list-style-type: none">• Clean the intake air filter. See the Operation manual.• Ensure that the electrical cord is properly grounded.
E016	Overheating of heat exchanger	<ul style="list-style-type: none">• Turn off the system for at least 30 minutes, and then restart it.• Clean the cold water inlet filter. See the Operation manual.• Flush the heat exchanger. See the Operation manual.
E030	Exhaust overheating the water heater shuts down when the flue temperature exceeds 65°C	<ul style="list-style-type: none">• Turn off the system for at least 30 minutes, and then restart it.• Clean the cold water inlet filter. See the Operation manual.• Flush the heat exchanger. See the Operation manual.
E046	Abnormal operation: limit control	Contact Technical Support at 1-800-519-8794.
E047	Abnormal operation: exhaust thermostat	Contact Technical Support at 1-800-519-8794.

Error Code	Reason	Self-diagnostic / Action
E060	Abnormal operation: dual venturi	Contact Technical Support at 1-800-519-8794.
E109	Abnormal operation: fan motor	Clean the intake air filter. See the Operation manual.
E110	Abnormal air pressure	<ul style="list-style-type: none"> • Ensure that the exhaust pipe is free of obstructions. • Clean the intake air filter. See the Operation manual.
E407	Hot water outlet: thermostat open or short circuit	Contact Technical Support at 1-800-519-8794.
E421	Cold water inlet1: thermostat open or short circuit	Contact Technical Support at 1-800-519-8794.
E432	Cold water inlet2: thermostat open or short circuit	Contact Technical Support at 1-800-519-8794.
E434	Abnormal operation: water adjustment valve	Contact Technical Support at 1-800-519-8794.
E438	Abnormal operation: circulation pump	<ul style="list-style-type: none"> • External: Ensure that all water supply and return lines are open. • Internal: Check the direction of the 2-way valve.
E439	Abnormal operation: flow sensor	Contact Technical Support at 1-800-519-8794.

Error Code	Reason	Self-diagnostic / Action
E441	Hot water inlet2: thermistor open or short.	Contact Technical Support at 1-800-519-8794.
E515	Abnormal operation: controller	Check the front panel settings.
E517	Abnormal operation: DIP switch setting	Check the settings for Circuit Board DIP Switch (See the Installation manual).
E593	Abnormal operation: front panel key	Contact Technical Support at 1-800-519-8794.
E615	Abnormal operation: input and memory	Contact Technical Support at 1-800-519-8794.
E736	Abnormal operation: cascade communication	Contact Technical Support at 1-800-519-8794.
E760	Flushing/service alarm	Contact the installer to perform routine service.
E782	Abnormal operation: main panel communication	Contact Technical Support at 1-800-519-8794.

Note If any of these remedies do not resolve the problem, contact Technical Support at 1-800-519-8794.

Memo

Memo

Memo

NAVIENT

Remote Controller Manual

www.navientinc.com

Navient America Inc.
20 Goodyear Irvine, CA 92618, TEL : 949-420-0420, FAX : 949-420-0420

Toll Free: 1-800-519-8794

BG-E-MU-10-01

